

IOGEAR USB to Serial Adapter Macintosh OS X Installation Instructions

NOTE: Please do not plug in your IOGEAR USB to Serial Adapter until **after** you have completed the below instructions.

- 1) Insert the IOGEAR CD-ROM into your Mac. You will see the IOGEAR CD on your Desktop.



- 2) Double-click the IOGEAR Logo, you will see the CD-ROM Contents.



- 3) Double-click the Mac OS 10 folder.



- 4) You will now see the Extensions Package for Mac OS X.




PL2303_1.0.8.pkg


- 5) Double-click the **PL2303_1.0.0.pkg**.
- 6) The USB to Serial Cable driver installation will appear. Click **Continue**.



- 7) You will now be asked where you would like to install the driver package. Select the Hard Disk that contains your Mac OS X (or “10”) partition, then click **Continue**.



- 8) You will now be asked if you wish to perform a basic installation of the software package on your Mac OSX volume. Click **Install**.




- 9) You will now be asked for your Mac OSX login password. If you do not have this password, or do not know what it is, you may need to contact your Network Administrator. Otherwise, it is the password you entered when you first setup your Macintosh. Most often, this is left blank, so you may not have a password to enter.

Click **OK**



- 10) You will receive a small prompt, letting you know that your machine will be restarted after you have completed the installation of the USB to Serial Adapter. Click **Continue Installation**.



- 11) Once the installation procedure is completed, click **Restart**.

